









Patio Deck Assembly Instructions

STOP! Before you assemble the deck make sure you have a flat surface, ideally gravel. If it is to be placed on the lawn, we recommend cutting the grass as short as possible before assembling your new deck over it.

 <p>1. Unroll the foundation</p>	 <p>2. Install 2 X 4-28" long foundation spreader boards between 2 X 4 foundations sleepers.</p>	 <p>3. Complete installation of 6, 2 X 4-28" spreader boards as illustrated</p>
 <p>4. Install 1st - 64" 2 X 2 rim board as illustrated, pre-drilled holes facing up, use supplied 3 inch screws.</p>	 <p>5. Install the first 2 deck tiles as shown. Deck tiles can be installed linear or parquet.</p>	 <p>6. With a hammer install patented clip using 1 X 2 driver provided. Insure the tabs are driven into space between the deck tile boards. This locks the deck tile to the foundation.</p>
 <p>7. Screw down patented clip with 1/4 inch screws provided.</p>	 <p>"Setting Prong" Patented clip</p> <p>7a. The setting prong is what holds the 3rd and 4th deck to the foundation</p>	 <p>8. Set third deck tile into patented clip 'setting prong' by using the provided 1 X 2 driver board. You will probably need to hit the driver board several times with the hammer to set the deck tile tight to the foundation.</p>



9. Place 4th deck tile, set this deck tile onto foundation using the driver board into the patented clip "prong".



10. Install last rim boards using the 3 inch screws provided.

Relax and Enjoy Your New Patio Deck

