





Sidewalk "S" Kit Assembly Instructions

STOP! Before you assemble the deck make sure you have a flat surface, ideally gravel. If it is to be placed on the lawn, we recommend cutting the grass as short as possible before assembling your new kit over it.

<p>1. Unroll the deck foundation</p>	<p>2. Install the 4 -2x4, 28" long foundation spreader boards between the 2 foundations sleepers that are attached to the mesh.</p>
	
	
<p>3. Install the 2x2 rim boards on one side using the 3" screws supplied into the pre-drilled holes</p>	<p>4. Insert your tiles onto the pre-set Velcro strips</p>



5. Install the last 2, 2x2, 32" rim boards